


JENN-AIR® Countertop Microwave Ovens

PRODUCT MODEL SERIES

JMC1150W

Electrical: A 120-Volt, 60-Hz, AC-only, 15- or 20-amp fused electrical supply with a fuse or a circuit breaker. A time-delay circuit breaker is recommended. It is recommended that a separate circuit serving only this microwave oven be provided.

PRODUCT DIMENSIONS



| | |
|------------|--|
| Height (A) | 13 ¹³ / ₁₆ " (35.1 cm) |
| Depth (B) | 23" (58.4 cm) |
| Width (C) | 23 ³ / ₄ " (60.3 cm) |

LOCATION REQUIREMENTS

⚠ WARNING

Excessive Weight Hazard

Use two or more people to move and install microwave oven.

Failure to do so can result in back or other injury.

IMPORTANT: The control side of the microwave oven is the heavy side. Handle the microwave oven gently. The weight of the microwave oven is over 35 lbs (15.9 kg).

- Place the microwave oven on a cart, counter, table or shelf that is strong enough to hold the microwave oven and the food and utensils you place inside it.
- The microwave oven should be at a temperature above 50°F (10°C) for proper operation.

NOTE: Microwave oven may be built into a wall or cabinet, or over approved electric single oven only, using approved trim kits. See dealer for details.

- Do not block the exhaust vents or air intake openings. Allow a few inches of space at the back and side of the microwave oven where the exhaust vents are located. Blocking the exhaust vents could cause damage to the microwave oven, as well as poor cooking results.
- Make sure the microwave oven legs are in place to ensure proper airflow. If vents are blocked, a sensitive thermal device may automatically turn the microwave oven off. The microwave oven should work properly once it has cooled.