

JENNAIR®

Oven/Cooktop Combinations Electric Ovens

Any of the following built-in electric ovens can be installed under the following cooktops:

U.S.A.			Canada		
Oven	Cooktop		Oven	Cooktop	
Electric	Electric	Gas	Electric	Electric	Gas
JJW2427	JEC3430	JGC1530	JJW2427	JEC3430	JGC1530
JJW2430	JEC3536	JGC1536	JJW2430	JEC3536	JGC1536
JJW3430	JEC4424	JGC2530	JJW3430	JEC4424	JGC2530
	JEC4430	JGC2536		JEC4430	JGC2536
	JEC4536	JGC3536		JEC4536	JGC3536
	JIC4430	JGC7530		JIC4430	JGC7530
	JIC4536	JGC7636		JIC4536	JGC7636
	JIC4715	WCG52424		JIC4715	WCG52424
	JIE4115	JGC3115		JIE4115	JGC3115
	JIC4724	JGC3215		JIC4724	JGC3215
	JIC4730	JGC3530		JIC4730	JGC3530

JENNAIR®

Combinaisons four/ table de cuisson Fours électriques

Chacun des fours électriques encastrés ci-après peut être installé sous les tables de cuisson suivantes :

États-Unis			Canada		
Four	Table de cuisson		Four	Table de cuisson	
Électrique	Électrique	Gaz	Électrique	Électrique	Gaz
JJW2427	JEC3430	JGC1530	JJW2427	JEC3430	JGC1530
JJW2430	JEC3536	JGC1536	JJW2430	JEC3536	JGC1536
JJW3430	JEC4424	JGC2530	JJW3430	JEC4424	JGC2530
	JEC4430	JGC2536		JEC4430	JGC2536
	JEC4536	JGC3536		JEC4536	JGC3536
	JIC4430	JGC7530		JIC4430	JGC7530
	JIC4536	JGC7636		JIC4536	JGC7636
	JIC4715	WCG52424		JIC4715	WCG52424
	JIE4115	JGC3115		JIE4115	JGC3115
	JIC4724	JGC3215		JIC4724	JGC3215
	JIC4730	JGC3530		JIC4730	JGC3530