




REFRIGERATOR

MODELS:

JUWFL242HX02 (Left Hand, Overlay)



CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Cabinet (Not A Service Part)	11	W11359428	Cover, LED	20	W11361412	Fan Motor Assembly, Evaporator
2	W11846246	Assembly, Evaporator Cover	12	W11376132	Assembly, Separator			FOLLOWING PARTS NOT ILLUSTRATED
3	W11371095	Screw	13	W11359433	Assembly, Switch Box			
4	W11375760	Screw	14	W11359429	Upper, Wine Rack	W11747922	Wine Rack Glides Assembly	
5	W11266076	Defrost Sensor	15	W11359430	Lower, Wine Rack			
6	W11359415	Fuse, Temperature	16	W11360218	Plate, Kick			
7	W11359416	Defrost Holder and Heater	17	W11371097	Screw			
8	W11359423	Assembly, LED	18	W11747921	Glides, Wine Rack (Lower Right)			
9	W11359424	Cover, LED (Right)		W11747920	Glides, Wine Rack (Lower Left)			
10	W11395483	Cover, LED (Left)	19	W11728555	Sensor Pcc (Upper)			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11360655	Door Assembly
2	W11721450	Plate, Push
3	W11371095	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W11360661	Right Hinge (Top) / Left Hinge (Bottom)
	W11360664	Right Hinge (Bottom) / Left Hinge (Top)
5	W11360668	Gasket. Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W11770530	Sash, Gasket (Top/Bottom)
7	W11360666	Sash, Gasket (Side)

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576947	Clamp, Cord	10	W11360536	Assembly, Fan Motor	19	W11360595	Sound Pad, Compressor
2	W11371097	Screw	11	W10163273	Drier	20	W11375771	Bolt
3	W11360241	Water Pan, Evaporator	12	W11266075	Clamp	21	W11740249	Cord, Power
4	W11375763	Screw	13	W11721645	Assembly, IB Box	22	W11568821	Panel, Cover
5	W11837873	Main PCB	14	W11770534	Cover, Side	23	W11618463	Assembly, Power Cord
6	W11360596	Mount, Compressor	15	W11723875	Stopper			REFRIGERANT CHARGE
7	4344826	Screw	16	W11721659	Screw			52 grams (R600a)
8	W11265570	Washer	17	W11721657	Screw			
9	W11265578	Cover Box, PCB	18	W11721449	Compressor			