




ELECTRIC COOKTOP

MODELS:

KCIG556JSS10 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11267526	Glass Cooktop Assembly (Includes Stainless Trim)
2	W11669432	User Interface Assembly
3	W11279477	Cooktop Spring

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W11279478	Cooktop Support Bracket
5	W11302457	Filter Support
6	W11429952	Element (8 Inch) (Left Front and Right Rear)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W11429950	Element (6 Inch) (Left Rear and Right Front)
8	W11429957	Element (9.5 Inch) (Center)

INTERIOR PARTS



INTERIOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11788464	I100 Induction Domino Module Assembly	7		Power Board Farina (Not Serviced)
2		Power Board Ascari (Not Serviced)			FOLLOWING PARTS NOT ILLUSTRATED
3	W11251205	Blower Assembly (Domino)	W11249830		Communication Harness (IPC1 to IPC2)
4	W11788462	I100 IPC Induction Module Assembly	W11347982		Jumper Harness (HMI to IPC)
5		Power Board Ascari (Not Serviced)	W11249832		Communication Harness (IPC2 to IPC3)
6	W11246545	Blower Assembly	W11330269		Cord, Power (Includes Terminal Block/Nuts and Capacitor)
			8286642		Tape, Foam