




Dishwasher

MODELS:

KDTS264TPS2 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11692258	Handle Assembly (Stainless)	6	W11714460	Front Panel (Stainless, Includes Light Pipe, Badge and Barrel Nut)	11	W10692757	Barrel Nut, Front Panel
2	W11721083	Arm, Hinge (Left)	7	3400000	Screw	12	W11438978	Screw (Black)
	W11721082	Arm, Hinge (Right)	8	W11364953	Screw	13	W10687133	Set Screw
3	W11377160	Cross Brace, Door	9	W11038694	Insulation, Single Layer	14	W11749368	Badge
4	W11102920	Light Pipe	10	W11467733	Toe Panel (Black)	15	W10919859	Insulation, Front Panel
5	W11108979	Access Panel (Black)				16	W11049903	Stud, Mounting
						17	W10316572	Screw


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11812829	Console Assembly (Black, Includes Insert)	8	W11714324	Screw	15	W11050927	Seal, Console/Door
2	W11336943	Jumper, Door	9	W10348409	Screw	16	W11088985	Hanger, Control
3	W11258418	Screw	10	W11773240	Inner Door Assembly	17	W10348408	Screw
4	W10711884	Screw	11	W11563231	Seal, Door Bottom			
5	W11091934	Latch Assembly (Includes Switch)	12	W11795142	Wiring Harness, Main (Includes Thermostat)			
6	W11818200	Control, Electronic	13	W11695670	Wiring Harness, Inner Door			
7	W11397505	Fuse, In-line	14	W11092649	Dispenser Assembly			


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11120458	Tub Assembly (includes gasket)	15	W11429970	Water Inlet Assembly	25	W11725055	System, Door Opening
2	W11790726	Base, Terminal Box	16	W11455395	Leg, Leveling	26	W11536143	Heater Element Assembly
3	W11035860	Gasket, Tub	17	3378128	Washer, Pronged Cup	27	W11132441	Terminal Block
4	W11429974	Nut, Water Inlet	18	3400014	Screw, Grounding	28	W11094449	Tub Mount, Third Level Rack (Left)
5	W11090487	Strike, Latch	19	W10277003	Screw		W11256437	Tub Mount, Third Level Rack (Right)
6	W11296374	Screw	20	W11793873	Cover, Terminal Box	29	W10920244	Nut, Tub
7	W11753995	Seal, Cabinet	21	W10920122	Side Support, Tub (Left)	30	W11716258	Screw
8	W11025993	Drip Tray		W10920120	Side Support, Tub (Right)	31	W11697506	Guide, Door Opening System
9	W11025986	Funnel, Overfill Protection	22	W11788662	Shield, Tub Sound			
10	W11025988	Funnel Extension	23	W11048217	Tub Mount, Upper Rack			
11	8269145	Bracket, Undercounter	24	W11770373	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)			
12	W11165093	Cover, Tub Corner						
13	W11255994	Float Switch						
14	W11184083	Plug, Tub						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11035712	Pump Assembly	10	W11299377	Motor & Sump Assembly	21	W11163419	Bracket, Thermostat
2	W11034554	Sump with Seal (Includes Inlet Diffuser, Drain Vent Assy, Screw, Check Valve Assy and Diverter Valve-Motor)	11	W11450247	Isolator, Rear Motor	22	W11193089	Thermostat (Included with Main Wiring Harness)
3	W10891543	Diffuser, Inlet	12	W11250985	Hose, Pressure	23	W11025970	Fill Valve Assembly
4	W11050773	Drain Vent Assembly	13	W10900389	Hose, Suction	24	W11122851	Clamp, Hose
5	9741232	Screw	14	W11035709	Motor, Drain	25	W11036159	Hose
6	W10891547	Check Valve, Drain	15	W11131184	Hose, Drain	26	W11795523	Clip, Hose
7	W11789941	Wash Arm Assembly	16	W11175571	Disc, Diverter	27	W10466656	Clamp, Hose
8	W11758980	Clamp, Hose	17	W11497568	Bracket, Rear Motor	28	W11036287	Hose, Inlet
9		Diverter Valve Motor (Not Serviced)	18	W11418271	Fastener	29	W11236576	Clamp, Hose
			19	W11126174	Indicator, Optical Wash			
			20	370445	Clamp, Hose			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11507999	Feed Tube Assembly	5	W11128231	Cover, Diverter	8	W10891539	Screen
2	W11039888	Retainer	6	W10892836	Retainer, Docking (2nd Level)	9	W11043437	Sprayarm, Upper
3	W11039869	Sprayarm, Third Level	7	W10891533	Filter			
4	W11043452	Manifold						

UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Illus.
No.

Part No.

Description

1	W11807556	Dishrack, Upper
2	W11441109	Track, Dishrack
3	W11133748	Mount Assembly


Illus.
No.

Part No.

Description

4	W11084872	Track Stop, Rear
5	W11084874	Track Stop, Front


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11807563	Dishrack, Lower
2	W11133747	Wheel and Transport Assembly
3	W11740263	Silverware Basket Assembly

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11441109	Track, Dishrack	3	W11048219	Wheel	4	W11084874	Track Stop, Front
2	W11733959	Rack, Third Level				5	W11084872	Track Stop, Rear

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396277	Moisture Barrier Kit
	W11381654	External Drain Hose, 12ft
	W11365011	Power Cord Kit (Straight)
	W11365014	Power Cord Kit (Right Angle)
	4396672	Strain Relief, Power Cord (Metallic)
	W10685193	Compression Hose Fitting, Water Line
	W10278635RP	Fill Hose Kit