




REFRIGERATOR

MODELS:

WRFC3036RZ03 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11354191	Top Hinge Assembly (Right Hand)	9	W11681218	Air Separator Assembly	24	W10705239	Door Wire Retainer
2	W11342589	Top Hinge Assembly (Left Hand)	10	W11681219	Air Separator Assembly (Cabinet)	25		Cabinet (Not a Servicable Part)
3	W11561088	Roller Bracket Assembly (Left Hand)	11	W11797551	Unit Cover Assembly	26	W11796059	Fill Tube Assembly
4	W11561087	Roller Bracket Assembly (Right Hand)	12	W11808291	Pivot Block	27	W11822576	Cabinet Fill Tube
5	W11799814	Hinge Cover Assembly (LH, Includes Reed Switch and Foil)	13	W11777328	Dual Valve	28	W11252188	Double Lock Ring
6	W11799809	Hinge Cover Assembly (RH, Includes Reed Switch and Humidity Sensor)	14	W11701312	Lid HV Assembly	29	W11175631	Locking Ring (5/16)
7	W11553339	Center Hinge Assembly (Left Hand)	15	W11729359	Screw	30	W10285005	Axle, Roller
8	W11554905	Center Hinge Assembly (Right Hand)	16	W11551460	Tube Inlet	31	M0108107	Clamp, Tube
			17	W11768632	Filter Outlet Tube	32	W11087168	Clip, Roller
			18	W11548358	Reed Switch	33	W11438184	Screw
			19	W11814926	Electronic Control	34	W10142287	Screw
			20	W11676389	Air Bottom Separator	35	W10141645	Screw
			21	W11768995	Icemaker Water Tube	36	694091	Screw
			22	W11541794	Triple Valve Bracket	37	W10001260	Screw
			23	W10505294	Door Coupler	38	12990504	Screw
						39	12992601	Screw (Door Wire Ground)


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11768672	Water Reservoir	10	W11615361	Air Return Grille	18	W11611401	Water Filter Housing Cover (Lower)
2	W11803101	Water Filter Housing	11	W11669736	Thermistor, Refrigerator Temperature	19	W11775450	Water Tube Holder
3	W11589849	Tower Cover	12	W11608354	False Wall	20	W11777021	Microswitch
4	W11536439	Water Filter	13		Liner (Not A Serviceable Part)	21	W11769079	Dispenser Fascia
5	W11512870	Damper Assembly	14	W11598835	LED Light Module	22	W11549348	Sky Light LED Panel
6	W11669931	Water Filter Housing Plug	15	W11608474	Screw Cover	23	W11612596	Sky Light Lens (White Fog)
7	W11717382	Pantry Jumper Assembly	16	W11724694	Port Lid Assembly	24	W11836232	Sky Light Trim (White)
8	W11733721	EPS Holder	17	W11608360	Lower False Wall	25	W11836816	Air Tower Gasket (Top)
9	W11608374	Air Return Duct Grille				26	12991701	Screw (Stainless)


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	6	W11569938	Heat Shield	11	W11563437	Air Dam (Right Hand)
2	W11646272	Evaporator Assembly	7	W11627842	Thermistor, Freezer Temperature	12	W10240370	Gasket, Evaporator Cover
3	W11228040	LED Light Module	8	W11560604	Defrost Heater			
4	W11609201	Evaporator Cover Assembly	9	W11365795	Defrost Heater Clip			
5	W11559742	Evaporator Wire Assembly (Includes Defrost Thermistor)	10	W11563438	Air Dam (Left Hand)			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11672796	Right Door Assembly (Stainless, Includes Door Gasket)	8	W11045530	Door Handle (Stainless)	17	W11681256	Door Stopper (Black, Right Hand)
2	W11672783	Left Door Assembly (Stainless)	9	W11586645	Refrigerator Door Gasket (Grey)	18	W11562282	Door Bushing (Grey, Right Hand)
3	W11549158	HMI Assembly	10	W11695930	Gallon Bin	19	W11562283	Door Bushing (Grey, Left Hand)
4	W11681260	Door Stopper (Black, Left Hand)	11	W11692521	Bottom Bin (Right Hand)			
5	W11803648	Mullion Flipper Assembly	12	W11579654	Gallon Bin			
6	W11685003	Door Duct Retainer	13	W11692526	Bottom Bin (Left Hand)			
7	8281136	Screw	14	W10884773	Badge			
			15	W11328753	Screw			
			16	W11719970	Retainer Plug			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11679880	Freezer Door Assembly (Stainless)	8	W11578810	Adapter Assembly (Right Hand)	16	W11612780	Pan Support
2	W10277361	Gear Collar	9	W11632631	Slider Basket	17	W11604038	Pan Support
3	W11658592	Reed Switch Holder	10	W11611561	Shaft Rack Assembly (Bottom)	18	W11113841	Screw
4	W11534704	Basket Bottom Assembly	11	W11629546	Top Basket Assembly	19	W11727685	Bottom Basket Divider
5	W11586644	Freezer Door Gasket (Grey)	12	W10248555	Pan Roller	20	W11548358	Reed Switch
6	W11578447	Adapter Clip	13	W10839805	Roller Axle	21	W11644790	Ice Maker Air Duct Assembly
7	W11578796	Adapter Assembly (Left Hand)	14	W11611610	Ice Bucket	22	W10277360	Gear, Spur
			15	W11608631	Icemaker Assembly			

UNIT PARTS



UNIT PARTS

Illus.
No. Part No. Description

1	W11543386	Compressor Baseplate
2	W11417341	Screw
3	W11678106	Water Tray
4	W10806346	Grommet, Compressor
5	W11668494	Condenser Assembly
6	W11614556	Suction Tube Assembly
7	W11754926	Compressor


Illus.
No. Part No. Description

8	W11613932	Condenser Fan Assembly
9	W11610529	Precooler Assembly
10	W11786369	Inverter Box Assembly
11	W11559668	Drain Tube Extension
12	2215468	Sound Insulation
13	W10774846	Roller
14	W11613272	Front Shroud
15	W11682571	Inverter Connector Cover

Illus.
No. Part No. Description

16	W11642492	Baseplate Gasket
17	W11613273	Roller Cover
18	W10805035	Drier (Service Drier Without Dye)
19	W11611636	Rear Shroud
20	W11728244	Wire Harness Assembly
		REFRIGERANT CHARGE
		60 grams (R600a)

SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11579004	Stationary Shelf Assembly	10	W11611176	Shelf Ladder (Left Hand)	17	W11753660	Pantry Base (Includes Thermistor Assembly)
2	W11753408	Pantry Crisper Assembly	11	W11611177	Shelf Ladder (Right Hand)	18	W11753665	Center Support Assembly
3	W11664743	Glass Crisper Cover	12	W11611181	Shelf Ladder (Center)	19	W11753389	Crisper Adapter (Left Hand)
4	W10840918	Side Support Flange	13	W11606482	Crisper Roller Assembly	20	W11753387	Crisper Adapter (Right Hand)
5	W11753454	Pantry Lid Cover	14	W11607351	Side Support Knob	21	W10804977	Screw (White)
6	W11753403	Crisper Pan Roller (Left Hand)	15	W11753417	Pantry Adapter Assembly (Left Hand)	22	W11755093	Thermistor Wire Assembly (Pantry)
7	W11753402	Crisper Pan Roller (Right Hand)	16	W11753418	Pantry Adapter Assembly (Right Hand)			
8	W10834284	Screw (Grey)						
9	W11753456	Crisper Cover Frame						

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10134625	Paint, Touch-up (Apollo Grey, 1/2 oz.)
		MISCELLANEOUS
	212643	Sealer, Gum (4 Ft)
	876370	Insulation (Set of 2, 3 x 24 x 48 in)
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 oz)
	833938	Terminal Connector Kit
	8003RP	Water Inlet Kit
	W10300794	Handle Installation Kit