




Dishwasher

MODELS:

WDTS8024SZ1 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11554913	Handle (Stainless)	7	3400000	Screw	16	W10316572	Screw
2	W11721083	Arm, Hinge (Left)	8	W11364953	Screw	17	W10919861	Insulation, Front Panel
	W11721082	Arm, Hinge (Right)	9	W11038694	Insulation, Single Layer			
3	W11377160	Cross Brace, Door	10	W11467733	Toe Panel (Black)			
4	W11102920	Light Pipe	11	W10692757	Barrel Nut, Front Panel			
5	W11108979	Access Panel (Black)	12	W11438978	Screw (Black)			
6	W11735241	Front Panel - (Stainless, Includes Light Pipe, Barrel Nut and Badge)	13	W10693137	Screw, Set			
			14	W10884775	Badge			
			15	W11049903	Stud, Mounting			


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11715533	Console Cap (Black)	8	W11714324	Screw	14	W11092649	Dispenser Assembly
2	W11084865	Jumper, Door	9	W10348409	Screw	15	W11050927	Seal, Console/Door
3	W11258418	Screw	10	W11773240	Inner Door Assembly	16	W11088985	Hanger, Control
4	W10711884	Screw	11	W11563231	Seal, Door Bottom	17	W10348408	Screw
5	W11091934	Latch Assembly (Includes Switch)	12	W11810483	Wiring Harness, Main (Includes Thermostat and Fuse)	18	W11397505	Fuse, In-line
6	W11812175	Control, Electronic						
7	W11723164	Housing, UI	13	W11695670	Wiring Harness, Inner Door			


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11120458	Tub Assembly (includes gasket)	15	W11429970	Water Inlet Assembly	25	W11697506	Guide, Door Opening System
2	W11790726	Base, Terminal Box	16	W11455395	Leg, Leveling	26	W11561776	Heater Element Assembly
3	W11035860	Gasket, Tub	17	3378128	Washer, Pronged Cup	27	W11094449	Tub Mount, Third Level Rack (Left)
4	W11429974	Nut, Water Inlet	18	3400014	Screw, Grounding		W11256437	Tub Mount, Third Level Rack (Right)
5	W11090487	Strike, Latch	19	W10277003	Screw	28	W11132441	Terminal Block
6	W11296374	Screw	20	W11793873	Cover, Terminal Box	29	W10920244	Nut, Tub
7	W11753995	Seal, Cabinet	21	W10920122	Side Support, Tub (Left)	30	W11725055	System, Door Opening
8	W11025993	Drip Tray		W10920120	Side Support, Tub (Right)	31	W11716258	Screw
9	W11025986	Funnel, Overfill Protection	22	W11158115	Shield, Tub Sound			
10	W11025988	Funnel Extension	23	W11048217	Tub Mount, Upper Rack			
11	8269145	Bracket, Undercounter	24	W11770373	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)			
12	W11165093	Cover, Tub Corner						
13	W11255994	Float Switch						
14	W11184083	Plug, Tub						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11122133	Pump Assembly	13	W10900387	Hose, Suction	26	W11795523	Clip, Hose
2	W11034556	Sump (includes Seal and Diverter)	14	W11035709	Motor, Drain	27	W10466656	Clamp, Hose
3	W10891545	Diffuser, Inlet	15	W11131184	Hose, Drain	28	W11036287	Hose, Inlet
4	W11294350	Hanger, Front Motor	16	W10903468	Disc, Diverter	29	W11418271	Fastener
5	9741232	Screw	17	W11025963	Bracket, Rear Motor	30	W11294352	Isolator, Front Motor
6	W10891547	Check Valve, Drain	18	W11236576	Clamp, Hose	31	W10380239	Ring, Volute
7	W11789942	Wash Arm Assembly	19	W11126174	Indicator, Optical Wash	32	W11108699	Filter Assembly
8	W11758980	Clamp, Hose	20	370445	Clamp, Hose	33	W10467002	Screw
9		Diverter Valve Motor (Not Serviced)	21	W11163419	Bracket, Thermostat	34	W10753070	Capacitor
10	W11345228	Motor & Sump Assembly	22	W11193089	Thermostat (Included with Main Wiring Harness)			
11	W11036663	Isolator, Rear Motor	23	W11025970	Fill Valve Assembly			
12	W11250985	Hose, Pressure	24	W11122851	Clamp, Hose			
			25	W11036161	Hose			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10872558	Feed Tube Assembly	6	W10892836	Retainer, Docking (2nd Level)	8	W10892835	Retainer, Docking (3rd Level)
2	W11039888	Retainer	7	W11039864	Grate	9	W11043437	Sprayarm, Upper
3	W11039869	Sprayarm, Third Level						
4	W11043452	Manifold						
5	W10903465	Cover, Diverter						

UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Illus.
No.

Part No.

Description

1	W11807557	Dishrack, Upper
2	W11441109	Track, Dishrack
3	W11180605	Clip, Adjuster Arm
4	W11084872	Track Stop, Rear
5	W11084874	Track Stop, Front

Illus.
No.

Part No.

Description

6	W11734029	Rack Adjuster (Left)
	W11734028	Rack Adjuster (Right)
7	W11807564	Tine Row, Fold Down
8	W11711810	Positioner


Illus.
No.

Part No.

Description

9	W11179753	Clip, Pivot
10	W11180178	Leveler, Adjuster Arm
11	W11734033	Button, Adjuster Arm
12	W11048219	Wheel


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11807554	Dishrack, Lower	3	W11740261	Silverware Basket	4	W11807547	Tine Row, Fold Down
2	W11133747	Wheel and Transport Assembly				5	W11711811	Retainer, Flex Row

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11441109	Track, Dishrack	5	W11725488	Manifold, Front	10	W11084872	Track Stop, Rear
2	W11807561	Rack, Third Level	6	W11193057	Manifold, Rear	11	W11084874	Track Stop, Front
3	W11048219	Wheel	7	W11175552	Tube, Wash			
4	W11231350	Mount Assembly, Third Level (Left)	8	W11175564	Manifold Assembly			
	W11231352	Mount Assembly, Third Level (Right)	9	W11783632	Silverware Tray			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396277	Moisture Barrier Kit
	W11381654	External Drain Hose, 12ft
	W11365011	Power Cord Kit (Straight)
	W11365014	Power Cord Kit (Right Angle)
	4396672	Strain Relief, Power Cord (Metallic)
	W10685193	Compression Hose Fitting, Water Line
	W10278635RP	Fill Hose Kit