




REFRIGERATOR

MODELS:

KRFC536SJP04 (Juniper)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Cabinet (Not a Servicable Part)	7	W11553339	Center Hinge Assembly (Left Hand)	18	W11548358	Reed Switch
2	W11808292	Pivot Block	8	W11554905	Center Hinge Assembly (Right Hand)	19	W11837352	Callisto Control Board
3	W11561088	Roller Bracket Assembly (Left Hand)				20	W11676389	Air Bottom Separator
	W11561087	Roller Bracket Assembly (Right Hand)	9	W11681218	Air Separator Assembly	21	W11454781	Dual Water Valve
4	W11342589	Top Hinge Assembly (Left Hand)	10	W11681219	Air Separator Assembly (Cabinet)	22	W11541794	Triple Valve Bracket
	W11354191	Top Hinge Assembly (Right Hand)	11	W11797551	Unit Cover Assembly	23	W10505294	Door Coupler
5	W11799815	Hinge Cover, Black (LH, Includes Reed Switch and Foil)	12	W11768988	Cabinet Water Fill Tube	24	W10705239	Door Wire Retainer
6	W11799810	Hinge Cover, Black (RH, Includes Switch, Sensor and Wifi Control)	13	W11576656	Water Dispenser Tube	25	W11252188	Double Lock Ring
			14	W11701312	Lid HV Assembly			
			15	W11729359	Screw			
			16	W11618006	Inlet Tube			
			17	W11768632	Filter Outlet Tube			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	W11733721	EPS Holder	15	W11768672	Water Reservoir
2	W11803103	Water Filter Housing	9	W11608374	Air Return Duct Grille	16	W11724694	Port Lid Assembly
3	W11589849	Tower Cover	10	W11615361	Air Return Grille	17	W11608364	Lower False Wall
4	W11536439	Water Filter	11	W11669736	Thermistor, Refrigerator Temperature	18	W11549348	Sky Light LED Panel
5	W11509880	Damper Assembly				19	W11612596	Sky Light Lens (White Fog)
6	W11669932	Water Filter Housing Plug (Grey)	12	W11790387	False Wall	20	W11836233	Sky Light Trim (Grey)
7	W11717382	Pantry Jumper Assembly	13	W11598836	LED Light Module	21	W11836816	Air Tower Gasket (Top)
			14	W11611458	Water Filter Housing Cover			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	5	W11559733	Evaporator Wire Assembly	10	W11563438	Air Dam (Left Hand)
2	W11646272	Evaporator Assembly	6	W11620573	Icebox Fan Assembly	11	W11563437	Air Dam (Right Hand)
3	W11228040	LED Light Module	7	W11627842	Thermistor, Freezer Temperature	12	W11520308	Heat Shield
4	W11608168	Evaporator Cover Assembly (Includes Fan Motor and Thermistor)	8	W11560604	Defrost Heater			
			9	W11365795	Defrost Heater Clip			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11846174	Left Door Assembly (Juniper, Includes Door Gasket)	10	W11657108	Gallon Bin (Right Hand)	19	W11328753	Screw
2	W11690372	Right Door Assembly (Juniper, Includes Door Gasket)	11	W11657111	Bottom Bin (Right Hand)	20	W11719970	Retainer Plug
3	W11567179	Ice Door Assembly	12	W11657115	Dispenser Bin (Left Hand)	21	W11589852	Cover Screw
4	W11681260	Door Stopper (Black, Left Hand)	13	W11681256	Door Stopper (Black, Right Hand)	22	W11611713	Supply Gasket
5	W11803651	Mullion Assembly	14	W11657124	Trivet Bin (Ice Door)	23	W11562282	Door Bushing (Grey, Right Hand)
6	W11685003	Door Duct Retainer	15	W11740632	Door Supply Duct Assembly	24	8281136	Screw
7	W11754953	Dispenser Water Tube	16	W11740633	Return Duct Assembly	25	W11562283	Door Bushing (Grey, Left Hand)
8	W11682896	Handle Assembly (Juniper)	17	W11768233	Temperature UI Assembly			
9	W11586645	Refrigerator Door Gasket (Grey)	18	W11688412	Badge			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11690378	Freezer Door Assembly (Juniper, Includes Door Gasket)	7	W11750020	Adapter Assembly (Left Hand)	13	W10839805	Roller Axle
2	W10277361	Gear Collar		W11750021	Adapter Assembly (Right Hand)	14	W11553901	Reed Switch
3	W11658593	Reed Switch Holder	8	W11727686	Bottom Basket Divider	15	W11682891	Handle Assembly (Juniper)
4	W11534705	Bottom Basket Assembly	9	W11632631	Slider Basket	16	W11612780	Pan Support
5	W11586644	Freezer Door Gasket (Grey)	10	W11611561	Shaft Rack Assembly (Bottom)	17	W11604038	Pan Support
6	W11614114	Clip Adapter	11	W11536451	Top Basket Assembly	18	W11113841	Screw
			12	W10838061	Pan Roller	19	W11328753	Screw


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11543386	Compressor Baseplate	10	W11684787	Retainer Bracket	21	W11786370	Inverter Box Assembly
2	W11417341	Screw	11	W11559668	Drain Tube Extension	22	W10805035	Drier (Service Drier Without Dye)
3	W11678106	Water Tray	12	2215468	Sound Insulation			REFRIGERANT CHARGE
4	W10806346	Grommet, Compressor	13	W10774846	Roller			65 grams (R600a)
5	W11668494	Condenser Assembly	14	W11613272	Front Shroud			
6	W11614556	Suction Tube Assembly	15	W11682571	Inverter Connector Cover			
7	W11606479	Compressor	16	W11642492	Baseplate Gasket			
8	W11613932	Condenser Fan Assembly	17	W11613273	Roller Cover			
9	W11610529	Precooler Assembly	18	W11728244	Wire Harness Assembly			
			19	W11611636	Rear Shroud			
			20	2223913	Clip			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11579005	Stationary Shelf Assembly	12	W11580666	Shelf Ladder (Center)	23	W11691589	Wine Rack
2	W11704911	Pantry Crisper Assembly	13	W11612888	Full Shelf Assembly	24	W11775515	Platter Frame
3	W11664614	Glass Crisper Cover	14	W11608888	Knob Side Support	25	W11664741	Platter Glass
4	W11608879	Crisper Pan Assembly (Left Hand)	15	W11579712	Pantry Adapter (Grey, Left Hand)	26	W11612881	Shelf Adapter (Left Hand)
5	W11613545	Pantry Lid Cover	16	W11579721	Pantry Adapter (Grey, Right Hand)	27	W11612883	Shelf Adapter (Right Hand)
6	W11836231	Crisper Pan Assembly (Right Hand)	17	W11718149	Pantry Base (Includes Thermistor Assembly)	28	W11565942	Pantry Glide (Left Hand)
7	W11651976	LED, Crisper Strip	18	W11608860	Center Support Assembly	29	W11540928	Pantry Glide (Right Hand)
8	W11666151	Pantry Adapter Cover (Left Hand)	19	W11608863	Crisper Adapter Assembly (Left Hand)	30	12990302	Screw
	W11666169	Pantry Adapter Cover (Right Hand)	20	W11608866	Crisper Adapter Assembly (Right Hand)	31	W11559750	Thermistor Wire Assembly (Pantry)
9	W11608868	Crisper Cover Frame	21	W11677826	Undershelf Wine Assembly	32	W10834284	Screw (Grey)
10	W11599143	Ladder Shelf (Right Hand)	22	W10840918	Side Support Flange	33	W10804977	Screw (White)
11	W11580665	Shelf Ladder (Left Hand)						


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	8	W11577793	Microswitch, Limit	14	W11762788	LED Strip Assembly (Juniper, Left Hand)
2	W11775967	Dispenser UI Assembly (Black Ore)	9	W11767995	Dispenser Drip Tray (Juniper)		W11762790	LED Strip Assembly (Juniper, Right Hand)
3	W11762782	Dispenser Well Assembly (Juniper)	10	W11762391	Bracket Assembly (Ice Door Motor)			
4	W11754979	Spigot Tube Assembly	11	W11762566	Dispenser Top Nozzle Assembly (Includes Proximity Sensor)			
5	W11769569	Dispenser Separator	12	W11767997	Dispenser Bottom Nozzle Assembly (Includes Camera and Level Sensor)			
6	W11767993	Dispenser Tray (Juniper)						
7	W10663682	Torsion Spring (Dispenser Pad)	13	W11728424	Dispenser Tube Seal			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11621160	Icemaker Assembly	4	W11620276	Ice Bin Assembly	6	W11722714	Dispenser Motor
2	W11603209	Ice Chute Assembly	5	W11363574	Motor Shaft	7	8281163	Screw (Stainless)
3	W10291905	Chute Gasket						

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W11766883	Paint, Touch-up (Juniper, 1/2 oz)
		MISCELLANEOUS
	212643	Sealer, Gum (4 Ft)
	876370	Insulation (Set of 2, 3 x 24 x 48 in)
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 oz)
	833938	Terminal Connector Kit
	8003RP	Water Inlet Kit